

LAUNDRY MASHER



INSTRUCTION MANUAL

Product structure



Product features:



Nano Silver
Infused
Ceramic
Beads



Fresh Linen
Scent



Detergent-
Free



Reusable



Hypoallergenic



Saves
Water



Saves
Energy



Eco-
Friendly

How to use

1. Always follow fabric care instructions. Wash colors and whites separately.
2. Pre-treat any stains before wash.
3. Place the load together with the Laundry Masher inside the washing machine.
4. Set to desired wash setting. It can be used with any temperature setting on your machine (max 70 C / 158 F).
5. Start Wash.

Warning

1. Do not put into tumble dryer.
2. Laundry Masher is not a toy and should be kept away from children and pets.

Product specification:

Product Size	64 x 93.5 x 65.5mm
Weight	99g




The device complies with the European Directives 2014/30/EU.

LAUNDRY MASHER



INSTRUCTION MANUAL

Product structure



Product features:



Nano Silver Infused Ceramic Beads



Pineapple Scent



Detergent-Free



Reusable



Hypoallergenic



Saves Water



Saves Energy



Eco-Friendly

How to use

1. Always follow fabric care instructions. Wash colors and whites separately.
2. Pre-treat any stains before wash.
3. Place the load together with the Laundry Masher inside the washing machine.
4. Set to desired wash setting. It can be used with any temperature setting on your machine (max 70°C / 158°F).
5. Start Wash.

Warning

1. Do not put into tumble dryer.
2. Laundry Masher is not a toy and should be kept away from children and pets.

Product specification:

Product Size	63 x 107 x 63mm
Weight	99.3g



The device complies with the European Directives 2014/30/EU.